

Diagramas_conexionado_xlrs_2015-2016

XLRSD2 (2015-2016) Diagramas de Conexionado

RXD2L + BOOTADMD

XVOSD2 + BOOTADMD

RXD2L + XVOSD2

RXD2L + XVOSD

RXD2SL + PIXHAWK

RXD2SL + PIXHAWK + XVOSD2

RXD2SH + PIXHAWK

RXD2SH + PIXHAWK + XOSDV2

Conexión XLRS para piloto

RXD2SH + PIXHAWK + XOSDV2 + ADAPTADOR PWM M2D + M2D GIMBAL

Conexión XLRS para piloto y observador

RXD2SH + PIXHAWK + XOSDV2 + ADAPTADOR PWM M2D + M2D GIMBAL

RXD2L + NAZA

Email: dmd@dmd.es

Teléfono: +34 961450346 (sólo Español)

Teléfono: 615 18 50 77 (sólo Español).

Skype: Vicente_dmd. (Inglés).

Skype: beatriz_dmd. (Español).



www.dmd.es



www.xlrs.eu



tienda.dmd.es

